Instruction Manual

Aroma Shooter ®



Table of contents

◆ Table of contents

- Introduction 3
- Safety precautions 4-6
- Package contents 7
- Technical specifications 8
- Components 9

◆ Before use

- How to load cartridges 10
- How to remove cartridges 11
- How to use 12
- Applications 13

◆ Other

- Disclaimer 14
- Support 17
- Contact 18

aromajoin

Before use

Thank you for purchasing the Aroma Shooter®.
For an optimal experience, we advise that you read this instruction manual prior to use.
We sincerely wish you enjoy your time with the Aroma Shooter® !

＜ About this instruction manual＞

Please note that due to continuous improvement of our products, some specifications or details in this manual are subject to change without notice.

Unauthorized reproduction or partial reproduction of this manual is strictly prohibited for commercial use.

Aroma Shooter® is a registered trademark of Aromajoin Corporation

Safety precautions

Please observe the following to ensure safe use of Aroma Shooter®.

Observing the safety precautions on the following pages is necessary to prevent personal injury and damage to property.

Safety sign :

	**WARNING**	Very high risk of death or serious injury
	**CAUTION**	High risk of death or serious injury
	**ATTENTION**	Risk of death or serious injury

Safety precautions

WARNING

- Do not use Aroma Shooter® in hot and humid places or near fire.
- To prevent accidental ingestion and misuse, do not leave Aroma Shooter® within reach of children.
- Do not Aroma Shooter® if you are sensitive to chemical substances.
- Stop immediate use of Aroma Shooter® if you experience any allergic symptoms such as itchy eyes or runny nose.

※ If you accidentally swallow an Aroma Cartridge, consult a doctor immediately.

CAUTION

- Do not disassemble, modify or repair Aroma Shooter® yourself.
- Do not put any metal objects such as wires in the USB port.
- Do not heat Aroma Shooter® or place it near or in fire.
- Do not put Aroma Shooter® near fire, stoves, direct sunlight or other high temperature places.
- Do not put Aroma Shooter® in water.
- Do not put Aroma Shooter® in a microwave oven or high-pressure containers.
- Do not use or store Aroma Shooter® in places with a lot of dust, humidity, oily smoke, or steam.
- Do not put any metal objects in contact with the bottom connector of Aroma Shooter®.

Safety precautions




ATTENTION


- Use Aroma Shooter® on a flat and stable table.
- Do not use in a closed and narrow space.
- When used for a long period of time, please ventilate the room.
- Aroma Shooter® is for indoor use only.
- Due to increased air flow, the use of Aroma Shooter® near a fan or air conditioner may prevent scent from reaching users' noses.
- Adjust shooting time and fragrance intensity according to the intended purpose of each use.
- If used under the proper conditions described in this manual, the warranty period for Aroma Cartridges is 3 months after the point of purchase.
- Remove the USB cable from the Aroma Shooter® USB port during extended periods of inactivity.
- Do not use detergent of any sort on the product.
- When storing Aroma Cartridges, in order to prevent oxidation and scent volatilization, store in a tightly-sealed container in a cool, dark place away from direct sunlight. Keep away from hot and humid places.
- Refrain from using Aroma Shooter® during pregnancy.
- Do not use Aroma Shooter® for other than its intended purpose.

Package contents

Included in the Basic pack box




Aroma Shooter® x 1



Aroma Cartridge Box x 2



Aroma Cartridge x 6



UBS Cable x 1



AC Adapter x 1



Quick Manual x 1


Technical specifications

Product	Aroma Shooter®
Model	AS2
Shooting Method	Air shooting
Number of cartridges	6
Connection	USB
	WiFi: 802.11 b/g/n/e/i (802.11n @ 2.4 GHz up to 150 Mbit/s) - Output power: Up to +20.5 dBm
	Bluetooth: v4.2 BR/EDR and Bluetooth Low Energy (BLE) - Output power: Up to +12 dBm
Scent switching time	0.1 sec
Shooting distance	60 cm
Shooting range	Diameter 60mm
LED	RGB　LED×2、Blue LED×1
Power	DC5V　2A　AC Adapter
	Average: 0.6W
Size	6.0 cm x 6.7 cm x 8.2 cm
Weight	150g (without cartridges)
Usage temperature	10～35℃
Storing temperature	0～35℃
Accessories	• Aroma Cartridges x 6 • AC Adapter x 1 • Cable x 1 ※ Exact content may differ per the details of your order.
Application	**Aroma Shooter App** https://aromajoin.com/software/apps


Components


On the Aroma Shooter® body, the channel numbers 1-6 are visible next to the Aroma Cartridge loading chambers when the lid is removed.

● Lid



● Body





LED will indicate the emitting channel.


	1	2	3	4	5	6
L LED	●	●	●			
R LED				●	●	●

※ The colors of each LED will blend when multiple chambers emit simultaneously.


Before use

How to load cartridges


1 Remove the magnetic lid by lifting from the grooved edge.



2 Take out each cartridge from its silver bag and discard the yellow protective tags.




3 Insert the cartridges such that the labels are visible, and the holed corners are grouped together at the center of the device.




Before use

How to remove cartridges


1 Remove the magnetic lid by lifting from the grooved edge.



2 Push on the top of a cartridge until you hear a click.



3 Safely pull the cartridge from Aroma Shooter® as shown in the picture.




Before use


How to use

1 To power Aroma Shooter®, either use the included AC adapter or connect the USB cable to your computer.

※If you do not have the AC adapter provided with the device, please use an 5V / 2A AC adapter.
Insufficient power may cause malfunction of the device.



2 Connect the USB cable to Aroma Shooter®.



3 Open the application on your tablet or mobile device.



Applications

To use an application, navigate to the link below, select the desired application, and download it.


https://aromajoin.com/software/apps



SDK

If you are an app developer, please select the appropriate SDK for your project after navigating the link below.

https://aromajoin.com/software/sdk



Disclaimer

Aromajoin Corporation is not responsible for the following matters:

- Aromajoin is not liable for any damages caused by fire, earthquake, tsunami, acts by a third party, other accidents, intentional or negligence of the customer, misuse, or use of Aroma Shooter® under other abnormal conditions.

- The Aroma Shooter® warranty does not make guarantees beyond those stated explicitly in this manual.

- Aromajoin is not responsible for any damages caused by usage of Aroma Shooter® other than that described in this instruction manual.

- Aromajoin is not liable for any damages due to malfunction resulting from connection with third-party devices and systems (damages may include interruption of normal business operation, loss of profit, loss of data, etc.).

- Aroma Shooter® is not intended for use in medical, nuclear, aerospace, and transportation settings. It is not intended for operation with other life-threatening or life-sustaining equipment, or in high-risk scenarios that require a high degree of reliability.

- If there is a hidden defect in your Aroma Shooter®, we will repair the defect free of charge or replace it with a defect-free or equivalent product, but Aromajoin is not liable for damages caused by such defects.

- Aromajoin will not offer repairs for bundled accessories such as USB cables and AC adapters.

Disclaimer

If you do not agree to this warranty, please return Aroma Shooter® to us. However, if the product is scratched or missing parts, due in part to user negligence, Aromajoin will not accept the return.

Aromajoin Corporation has a warranty period stated in this manual from the date of purchase. Do not use this product with medical devices that threaten or sustain life. When used for purposes that require high reliability, Aromajoin will not be liable for any damages or system failures.

1. If your Aroma Shooter® breaks down within the warranty period under normal use per this instruction manual and corresponding caution labels, etc., contact Aromajoin customer support immediately.

2. Customer support
   TEL: 090-6109-0591
   Email: contact@aromajoin.com

Disclaimer

3. Even within the warranty period, Aromajoin will charge for repairs in the following cases.

   ⑴ Product failure or damage due to misuse, unauthorized repair or modification by the customer.

   ⑵ Flood, salt, liquid, mist, fog, dropping, impact, sand or mud damage.

   ⑶ In cases of fire, pollution, abnormal voltage, earthquake or any damages caused by external causes such as natural disasters.

   ⑷ In cases where consumable items (such as Aroma Cartridges) are worn out or expire.

   ⑸ If the date of purchase and customer name are not correct on the warranty.

   ⑹ If the warranty is not presented

4. The warranty will not be reissued, so please keep it in a safe place.

※ The warranty guarantees repair under the period and conditions specified in this manual.

Support

Start

- **Aroma Shooter® doesn't work!**

→ Be sure that all cable are connected.

Connection

- **I can't connect Aroma Shooter® via Bluetooth / Wifi!**

→ To verify if your device connection is on, please check whether the serial number of your Aroma Shooter® is displayed on the app screen.

Cartridge

- **I can't remove the cartridge!**

→ Gently pull the cartridge out with a paper clip.

- **No scent is emitted from the cartridge!**

→ Make sure you have downloaded the appropriate app (see p.13) for your smartphone, tablet, or PC.

→ Check that the shoot holes are not clogged.

Warranty

Warranty			
	Product		Aroma Shooter® - AS2
	Warranty period		Date of purchase .. .. (Valid for 1 year from the date of purchase)
	Distributor: Aromajoin Corporation		
	Customer	Name	
		Address	
		Email	

aromajoin


Contact

If you have any questions, please contact us:

Aromajoin Corporation

105 ACT Kyoto, Jibu-cho, Fushimi-ku,
Kyoto 612-8374, Kyoto Prefecture

TEL: 090-6109-0591
Email: contact@aromajoin.com



※ Aroma Shooter® is a product built on a number of patented technologies related to "spatiotemporal control of fragrance."